









Interfaces PBX

Partner	Systems	from Version*	Requirements	Hospix Entry 2	Hospix Open 2	Notes
Alcatel-Lucent 	OmniPCX Enterprise	R11.01	AHL driver		✓	
	OmniPCX Office	V5	OHL/OLD driver	✓	✓	System-side restrictions in Call Accounting
	Aura Communication Manager	in preparation			✓	Wakeup and Room Status need Hospix VSS
	IP Office	R9.0	.NET installation	✓	✓	
	Unified Communications Manager (UCM)	V9.0			✓	Wakeup and Room Status need Hospix VSS
	innovaphone PBX	V10		✓	✓	Wakeup need Hospix VSS
	MiVoice Office 400	R2.1	Hospitality PMS Interface Hospitality PMS Rooms	✓	✓	Wakeup need Hospix VSS
	MiVoice 5000	R5.4			✓	Wakeup need Hospix VSS
	Mitel 100 OpenCom 100	R9.0	Open CSTA 100 .NET installation	✓	✓	
	OpenCom 1000	R5.1	CI Hotel/ alarm Connection data recording CDA	✓	✓	
	KX-TDE KX-NCP KX-NS	V1.1 V1.1 all versions	CSTA interface .NET installation	✓	✓	SIP terminals in the guest rooms do not support wakeup and room status
	Application Server	V5.0.3		✓	✓	Centrex only SIP, perhaps with Mediaconverter for a/b, S0
	HiPath 3000	V5	LIM or HG1500	✓	✓	
	HiPath 4000	V6			✓	Wakeup and Room Status need Hospix VSS
	OpenScope 4000	V7			✓	Wakeup and Room Status need Hospix VSS
	OpenScope Business	V1 R2	Booster card or booster server SW	✓	✓	

* Older versions on request